



Prima•Stratum

User's Guide

Engage Communication, Inc.
9565 Soquel Drive, Suite 201
Aptos, California 95003

TEL: 831-688-1021 FAX: 831-688-1421

www.engageinc.com
support@engageinc.com

Revision 7

Product Warranty

Seller warrants to Buyer that any unit shipped to Buyer, under normal and proper use, be free from defects in material and workmanship for a period of 24 months from the date of shipment to Buyer. This warranty will not be extended to items repaired by anyone other than the Seller or its authorized agent. The foregoing warranty is exclusive and in lieu of all other warranties of merchantability, fitness for purpose, or any other type, whether express or implied.

Remedies and Limitation of Liability

- A. All claims for breach of the foregoing warranty shall be deemed waived unless notice of such claim is received by Seller during the applicable warranty period and unless the items to be defective are returned to Seller within thirty (30) days after such claim. Failure of Seller to receive written notice of any such claim within the applicable time period shall be deemed an absolute and unconditional waiver by buyer of such claim irrespective of whether the facts giving rise to such a claim shall have been discovered or whether processing, further manufacturing, other use or resale of such items shall have then taken place.
- B. Buyer's exclusive remedy, and Seller's total liability, for any and all losses and damages arising out of any cause whatsoever (whether such cause be based in contract, negligence, strict liability, other tort or otherwise) shall in no event exceed the repair price of the work to which such cause arises. In no event shall Seller be liable for incidental, consequential, or punitive damages resulting from any such cause. Seller may, at its sole option, either repair or replace defective goods or work, and shall have no further obligations to Buyer. Return of the defective items to Seller shall be at Buyer's risk and expense.
- C. Seller shall not be liable for failure to perform its obligations under the contract if such failure results directly or indirectly from, or is contributed to by any act of God or of Buyer; riot; fire; explosion; accident; flood; sabotage; epidemics; delays in transportation; lack of or inability to obtain raw materials, components, labor, fuel or supplies; governmental laws, regulations or orders; other circumstances beyond Seller's reasonable control, whether similar or dissimilar to the foregoing; or labor trouble, strike, lockout or injunction (whether or not such labor event is within the reasonable control of Seller)

Copyright Notice

Copyright ©2011-2015 Engage Communication, Inc.

All rights reserved. This document may not, in part or in entirety, be copied, photocopied, reproduced, translated, or reduced to any electronic medium or machine-readable form without first obtaining the express written consent of Engage Communication. Restricted rights legend: Use, duplication, or disclosure by the U.S. government is subject to restrictions set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause in DFARS 52.227-7013 and in similar clauses in the FAR and NASA FAR Supplement.

Information in this document is subject to change without notice and does not represent a commitment on the part of Engage Communication, Inc.

FCC Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

NOTE - Shielded Telecommunication (T1 or E1) and Ethernet cables must be used with the Engage Prima•Stratum to ensure compliance with FCC Part 15 Class A limits.

CAUTION – To reduce the risk of fire, use only No. 26 AWG or larger listed Telecommunication cables.

Equipment Malfunction

If trouble is experienced with a Prima•Stratum, please contact the Engage Communication Service Center. If the equipment is causing harm to the telephone network, the telecommunications service provider may request that you disconnect the equipment until the problem is resolved.

Engage Communication Service Center:

Phone (U.S.) +1.831.688.1021

Fax +1.831.688.1421

E-mail support@engageinc.com

Web www.engageinc.com

Table of Contents

Chapter 1	1
Introduction	1
Prima•Stratum	1
LAN Interface	1
WAN Interface	1
GPS Antenna Interface	1
About this Guide	2
Organization	2
Intended Audience	2
Chapter 2	3
Installation QuickStart	3
Communication with the Prima•Stratum	3
Console Port	3
Telnet	3
Editing & Pasting Configurations	3
Ethernet Cabling	4
Serial Cabling	4
GPS Antenna Cabling	4
Prima•Stratum Configuration Parameters	4
Prima•Stratum System Parameters	4
Interface Specific Parameters	5
Chapter 3	6
Installation of the Prima•Stratum	6
Installation Requirements	6
Installing the Hardware	6
Locating the Prima•Stratum	6
Powering the Prima•Stratum	7
Console Port	7
Configuring the Engage Prima•Stratum for the LAN	7
Ethernet Interface	7
Prima•Stratum Serial Interface Options	8
T1 Interface	8
E1Interface	8
Prima•Stratum GPS Antenna Interface	8
BNC Interface	8
Status LEDs	8
Internal Switches	9
SNMP Support	9
Chapter 4	11

Configuration Examples	11
Example 1: T1 Configuration for ESF Framing and B8ZS Coding	11
Example 2: T1 Configuration for D4 Framing and AMI Coding	12
Example 3: E1 Configuration for CRC4 Framing and HDB3 Coding	13
Example 4: E1 Configuration for FAS Framing and AMI Coding	15
Example 5: T1 and E1 Configuration	16
Example 6: T1 and E1 Configuration for OCXO	17
Chapter 5	19
Command Line Interface	19
Console Communication	19
Logging in to the Prima•Stratum	19
Overview of Commands	19
Categories	20
Online Help	20
Configuration Modes	20
Syntax for Command Parameters	20
Show Config All	21
System Level or "General" Commands	21
Upgrade Firmware	22
SNMP Configuration	23
SHOW Commands	23
LAN Interface Statistics	24
Serial Interface Information	25
Serial Interface Statistics	25
SSHD Information	25
Config Interface Commands	25
Local Area Network Interfaces	26
DHCP Client	27
T1 Interface	29
E1 Interface	30
Chapter 6	31
Prima•Stratum Configuration & Operation	31
Prima•Stratum Installation Steps	31
System and Ethernet Parameters	31
T1 Parameters	31
T1 DSU/CSU Parameters	31
E1 Parameters	32
E1 DSU/CSU Parameters	32
T1/E1 Clocking Considerations	32
Prima•Stratum Cabling	32
Appendix	33
Prima•Stratum Specifications	33
GPS Locked Frequency Stability	33
GPS Holdover Frequency Stability - TCXO (loss of satellite signal)	33

OCXO Frequency Stability - Stratum IIIe	33
GPS Antenna Cable Specifications	33
Ethernet Port	33
Serial Interfaces Options	33
Power Supply	33
Physical	33
T1 Specifications	34
E1 Specifications	34
TFTP Online Upgrade Capable (FLASH ROMs)	34
Management	34
Prima•Stratum Dip Switch Settings-All Models	34
Table 1 - 10/100BaseT Port Specification	35
Table 2 - 10/100BaseT Port Specification #2	36
Table 3 - RJ45 to DB9 Cable Pinout	36
Table 4 - Console Port Pinout	37
Table 5 - 12 - 24 DCV Power Connector	38
Table 6 - -48 Power Connector	38
Copyright Notices:	39
Glossary	49
Terms and Concepts	49
General Networking Terms	49
TCP/IP Networking Terms	50
Other Terms	51

Chapter 1

Introduction

The Prima•Stratum User's Guide provides the information users require to install and operate the Prima•Stratum product. It is developed and manufactured by Engage Communication, Inc. The use of the Engage Prima•Stratum systems requires one Prima•Stratum. Cable connections and the setting of configuration variables are needed to install the Prima•Stratum.

Prima•Stratum

The Prima•Stratum model provides Stratum 1 level timing signals for interfacing TDM and IP based circuits. An optional OCXO Stratum IIIe oscillator can also be ordered which can be used as an alternate/backup clocking source

LAN Interface

The Prima•Stratum model features a five port 10/100BaseT Layer-2 Ethernet switch. These ports can be used for remote management.

WAN Interface

T1 interfaces offer an extremely accurate 1.544MHz/T1 reference clocks that are frequency locked to the Global Stratum 1 source.

E1 interfaces offer an extremely accurate 2.048MHz/E1 reference clocks that are frequency locked to the Global Stratum 1 source.

Note: An optional OCXO Stratum IIIe oscillator can also be ordered which can be used as an alternate/backup clocking source

GPS Antenna Interface

The GPS antenna interface allows the Prima•Stratum to use available GPS Satellites for Stratum 1 Clocking. This BNC interface is active, carrying voltage to the GPS antenna. Maximum recommended antenna cable distance is 10 meters. The antenna cable can be extended by proper use of line amplifiers. Although, it is much easier to extend the T1/E1 interface over long distances. Note: Antenna available for purchase as an option.

About this Guide

Organization

Chapter 1 - *Introduction* provides an overview of the Prima•Stratum User's Guide.

Chapter 2 - *QuickStart* provides concise configuration examples to get the experienced user up and running in a minimum of time.

Chapter 3 - *Installation* covers the physical environment and connections required when installing the Prima•Stratum. It also includes explanations of the Status LED's.

Chapter 4 - *Configuration Examples* is a collection of the more common configurations for various models and feature sets. These samples can be cut and pasted into the user interface as a shortcut in the configuration of Prima•Stratum units.

Chapter 5 - *Command Line Reference* provides a command-by-command description of the Engage CLI.

Chapter 6 - *Configuration and Operation* discusses the initial configuration and ongoing operation of the Prima•Stratum.

Appendices - Prima•Stratum specifications, connector pinouts and crossover wiring details.

Glossary - routers, networks, telecommunication and TCP/IP terminology.

Intended Audience

This manual is intended for experienced system administrators. The technical content is written for those who have basic computer, telecommunication and networking experience.

It is important that any administrator responsible for the installation and operation of Engage Prima•Stratum products be familiar with IP networking and data communication concepts, such as network addressing and synchronous serial interfaces. These concepts are central to an understanding of Prima•Stratum functionality. Several of the most common terms and concepts are covered in the Glossary section.

Chapter 2

Installation QuickStart

This *QuickStart* Chapter is intended for users who understand how they want their Prima•Stratum installed and configured and only require the mechanics of performing the installation. It includes the basic configuration of the unit. Refer to Chapter 4: *Configuration Examples* for cut and paste configuration.

Communication with the Prima•Stratum

Console Port

Initial communication with the Prima•Stratum is made through the Console port, utilizing the Command Line interface detailed in Chapter 5: *Command Line Interface*. Communication to the Console port should be set as:

9600 baud, 1 stop bit, no parity, 8 bit data, flow control none

The Console port on the Prima•Stratum utilizes an RJ45 jack. The Console port is configured as a DCE port. An RJ45/DB9 adapter is provided with the Prima•Stratum which permits a direct connection to DTE equipment, such as a COM connection of a PC.

Once a serial connection between a workstation and the Prima•Stratum Console port is established and a carriage return **<CR>** is entered, a **Login** prompt will appear.

The default login is: **root**.

No password is needed until it is set by the user, with the command **Passwd**.

Telnet

Once an IP address has been assigned to the Prima•Stratum Ethernet interface, the user can telnet into the Prima•Stratum from anywhere on the local network and continue configuration using the Command Line Interface.

Editing & Pasting Configurations

Users of the Command Line Interface, (CLI), have the option of editing standard Prima•Stratum configurations in a text editor and pasting that configuration to the Prima•Stratum. The examples in Chapter 4: *Configuration Examples* can be used as templates and include a variety of the most common configurations.

Edit the desired configuration listing using a simple text editor then connect to the Prima•Stratum through Telnet or the Console port and enter the configuration mode with the command: **config**.

Paste the edited text, comments and all, to the Prima•Stratum then issue the command: **save**. The Prima•Stratum will reset and come up with the new configuration.

To save a Prima•Stratum configuration, issue the command: **show configuration all** and save the response listing to a text file.

Ethernet Cabling

The Prima•Stratum model use standard or crossover 10/100BaseT Ethernet cabling to connect to any Ethernet device. The switch will auto-sense the required electrical connection for communication with the device it is connected to.

Serial Cabling

Typically, a crossover cable is required to connect the Prima•Stratum T1/E1 ports to the T1/E1 equipment interface. The Prima•Stratum T1/E1 is shipped with T1/E1 Crossover Cables that uses yellow cabling. Refer to the *Appendices* for the details of the wiring of this cable. Although, on some occasions a T1 standard cable may be needed.

GPS Antenna Cabling

The 50Ω BNC connector is located on the rear of the unit to attach a GPS antenna. This BNC cable carries voltage to the GPS antenna for operation. The maximum recommended cable length is 10 meters (30 feet). Custom cables can be made to extend the antenna signal, please see the Appendix for *GPS Antenna Cable Specifications*. Although, the T1/E1 interface can easily handle long distances. The recommended antenna is the Garmin GA-38 which is available as an option.

Prima•Stratum Configuration Parameters

The setup of the Prima•Stratum involves configuration of the following:

- Prima•Stratum System Parameters
- Interface Specific parameters

Examples are provided in Chapter 4: *Configuration Examples* and a complete description of all commands is available in Chapter 5: *Command Line Interface*.

Prima•Stratum System Parameters

System parameters include the Prima•Stratum Hostname, the Ethernet IP address and the default router.

Examples:

Host Name Aptos PrimaStratum

Note: Provide a unique name for the Prima•Stratum.

Ethernet IP address

IP ADDRESS aaa.bbb.ccc.ddd/ee

The IP address is applied on a per-interface basis.

Ethernet Broadcast Reception

The Ethernet interface can be configured to disable the reception of Broadcast and Multicast packets.

BroadcastRCV {ON | OFF}

Note: The Destination Prima•Stratum or the Default Router and any local device that wants to communicate with the Prima•Stratum needs to be configured with the MAC address of the Prima•Stratum in its ARP table. Due to the complexity involved in setting up the IP Address to Ethernet MAC address

manually it is recommended that BroadcastRCV be set to **On**, unless broadcast storms are expected on the network where the Prima•Stratum resides.

Prima•Stratum Default-Router

If there is a need to route to a different IP network the Default-Router must be entered. The Default Router is typically the local IP WAN Router.

IP DEFAULT-ROUTER aaa.bbb.ccc.ddd

Interface Specific Parameters

T1 Configuration Parameters

The Prima•Stratum T1 serial interface (S1), is configured for T1 operation at the factory. The following T1 parameters must match the configuration of the DS1/T1 interface to which it is connected. The **T1 Clocking** parameter in S2, S3 and S4 will be the same as S1, master clocking selector.

Interface S1

Type T1	
T1 Data	{Normal Invert}
T1 Clocking	{GPS OCXO GPSBackupOCXO}
T1 LBO	{CSU {0dB -7.5dB -15 dB -22.5dB} DSX-1 NN}
T1 Framing	{ESF D4}
T1 Coding	{B8ZS AMI}
T1 IdleCharacter	0xNN
T1 Channels	{Full}

Note: T1 Clocking OCXO is available for the Prima•Stratum as an upgradable option.

E1 Configuration Parameters

The Prima•Stratum E1 serial interface number 1, (S1), is configured for E1 operation by the manufacturer. The following E1 parameters must match the configuration of the E1 interface to which it is connected. The **T1 Clocking** parameter in S2, S3 and S4 will be the same as S1, master clocking selector.

Interface S1

Type E1	
E1 Data	{Normal Invert}
E1 Clocking	{GPS OCXO GPSBackupOCXO}
E1 Framing	{CRC4 FAS UNFRAMED}
E1 Coding	{HDB3 AMI}
E1 IdleCharacter	0xNN
E1 Channels	{Full}

Note: E1 Clocking OCXO is available for the Prima•Stratum as an upgradable option.

Chapter 3

Installation of the Prima•Stratum

This chapter provides details on the physical connections required for the installation of Engage Prima•Stratum equipment and the initial communication with the Prima•Stratum via the console port.

References are made to the *Configuration and Operation* of the Prima•Stratum as well as to the *Command Line Interface (CLI)*. These topics are covered in detail in later chapters.

Installation Requirements

The use of Engage Prima•Stratum system will create a Stratum 1 timing signals for interfacing TDM and IP based circuits. An optional OCXO Stratum IIIe oscillator can also be ordered which can be used as an alternate/backup clocking source

A standard Prima•Stratum package includes:

- Prima•Stratum unit - with installed WAN interfaces
- Console port adapter and cable
- One cross over T1/E1 cable per port
- RJ45 to DB15 male adapter for 120 ohm balanced (for E1 operation)
- Power Converter (110 or 220 Vac input/12 Vdc output)
- Documentation CD with *Prima•Stratum User's Guide*
- Optional - Weatherproof GPS Antenna with 10 meter cable and mounting hardware

Installing the Hardware

Locating the Prima•Stratum

Site consideration is important for proper operation of the Prima•Stratum. The user should install the unit in an environment providing:

- A well-ventilated indoor location
- Access within six feet of a power outlet
- Two feet additional clearance around the unit to permit easy cabling connection
- Within 10 meters where of the GPS Antenna will be mounted

The Prima•Stratum can be mounted on a standard 19 inch equipment rack, available from Engage.

Powering the Prima•Stratum

Engage Prima•Stratum units utilize an external power adapter, available in 110 VAC and 220 VAC versions, providing AC output.

The appropriate power adapter is provided with each unit. Ensure the power adapter is not connected to power before plugging the AC adapter into the rear panel power connector.

Connect the power adapter to an appropriate AC power outlet and check the power led on the front panel of the Engage Prima•Stratum. The power led will be a steady green when the internal diagnostics have completed.

Console Port

All Prima•Stratum models include a Console port for configuration. The Console port may be used for serial communication from a local workstation. Prima•Stratum models utilize an RJ45 jack for the Console port. The Console port is configured as a DCE (Data Communication Equipment) port.

An RJ45 to DB9 adapter is provided with the Prima•Stratum which provides a physical interface permitting direct connection to DTE equipment, such as the COM1 interface of a PC.

Pinouts for the Console port, as well as Engage supplied adapters, are provided in the *Appendices*.

Communication to the console port should be set for,

9600 baud, 1 stop bit, no parity, 8 bit fixed, flow control none.

Once a serial connection between a workstation and the Prima•Stratum Console port is established and a carriage return <CR> is entered, a **LOGIN** prompt will appear.

The default **Login** is: **root**.

No password is needed until it is user set. The command **PASSWD** can be used to set a password.

Configuring the Engage Prima•Stratum for the LAN

The Prima•Stratum needs to be configured with a number of parameters for proper operation on the local area network including:

- Ethernet IP address and subnet mask
- Default gateway if routing to another IP network

The configuration procedure depends on the network environment in which the Prima•Stratum is to be installed.

Note: It is strongly suggested that you configure the Prima•Stratum with its unique network identity before making any Ethernet or Wide Area connections.

Ethernet Interface

The Prima•Stratum uses a 10/100BaseT to connect to the Local Area Network. Each system provides five 10/100BaseT interfaces. ETH1 and ETH2 are for WAN connections, ETH3, ETH4 and ETH5 are connected to ETH1 internally and create a 4port switch.

Standard or crossover 10/100BaseT Ethernet cabling can be used to connect to any Ethernet device. The switch will auto-sense the required electrical connection for communication with the device it is connected to.

10/100BaseT Ethernet cabling and crossover pinouts are provided in the *Appendices*.

Prima•Stratum Serial Interface Options

T1 Interface

The internal T1 interfaces, (S1, S2, S3, or S4), are used to provide Stratum 1 timing signals. The interface connects to the T1 interface of T1 based telecommunication equipment such as a PBX or a T1 Multiplexer. This connection uses a panel RJ48 jack and accepts 8 pin modular plugs. T1 circuits use pins 1&2 for RxData and 4&5 for TxData. See *Appendices* for the T1 interface pinout.

All T1 configuration items, including Line Coding, Framing and Clock Source, are configurable using the Command Line Interface, (CLI).

E1 Interface

The internal E1 DSU/CSU permits direct connection to the E1 interface of E1 based telecommunication equipment such as a PBX or an E1 Multiplexer. This connection uses a panel RJ48 jack and accepts 8 pin modular plugs. E1 circuits use pins 1&2 for RxData and 4&5 for TxData. An RJ48/DB15 adapter cable is available if the E1 line is terminated in a 15 pin male "D" connector. See *Appendices* for E1 pinout and cable specification.

Note: The E1 interface is 120 ohm, balanced. The E1 RJ45 interface is converted to the E1 120 balanced DB15 Male interface via an RJ45 to DB15 male adapter.

All E1 configuration items, including Line Coding and Clock Source, are configurable using the Command Line Interface.

Prima•Stratum GPS Antenna Interface

BNC Interface

The 50Ω BNC connector is located on the rear of the unit to attach a GPS antenna. This BNC cable carries voltage to the GPS antenna for operation. The maximum recommended cable length is 10 meters (30 feet). Custom cables can be made to extend the antenna signal, please see the Appendix for *GPS Antenna Cable Specifications*. Although, the T1/E1 interface can easily handle long distances. The recommended antenna is the Garmin GA-38 which is available as an option.

Status LEDs

Front panel LEDs provide Power, Ethernet and Serial Interface status.

Power - The Power LED is normally green, although at power-on it may briefly blink if a firmware upgrade, (TFTP upgrade stored in the FLASH ROM) is being loaded.

Ethernet

The Prima•Stratum T1 provides specific information, with EthRX and EthTX indicators providing status on packet transmission and receipt, respectively, on the Ethernet interface:

- When receiving, the RxD will show GREEN
- When transmitting, the TxD will show GREEN

Serial Interfaces

The Prima•Stratum provides specific information, with ST and LNK indicators provide link status, communication processor and framing, respectively, from the T1/E1 device or line to which the Prima•Stratum is connected.

There are four indicators, S1 through S4 indicators providing status on valid framing from the T1/E1 device or line. Please note that the S1 through S4 indicators will only show connections for the amount of ports purchased:

- When the communication processor recognizes the port, ENA will show a steady GREEN. This will show the enabled ports.
- For correct framing status, LNK will indicate a steady GREEN. This shows that the Prima•Stratum is receiving correct framing.
- If the framing is removed or lost from the serial interface, the ST will light AMBER and the LNK will turn off.
- The TD and RD Leds are currently unassigned.

GPS Interface

The Prima•Stratum provides a visible LED on the rear of the unit. This LED will light GREEN when locked to GPS Satellites.

Internal Switches

The Prima•Stratum has a single push-button switch (SW2). When holding this switch during the boot cycle it will do the following:

- Force operation from Base Flash and delete downloaded upgrades.

The rear panel must be removed and the motherboard slid out slightly to access the switch.

SNMP Support

All Engage products support Simple Network Management Protocol, (SNMP) version 1. SNMP support provides access via IP to groups of administrative, configuration-related, and statistical information objects about the Engage device. An Ethernet connection to the device and a PC with an application which provides an SNMP version 1 client are required.

An SNMP client will query the device and display the information objects and their values to the user. Groups of SNMP information objects are referred to as MIBs (Management Information Base). The Engage Prima•Stratum products support most of MIB-II (MIB-2). Subgroups of information in MIB-II are listed below.

Please e-mail suport@engageinc.com for Engage Communication MIB Definitions.

System group: contains system information such as a designated system identifier, location, and vendor ID (Engage).

Interface group: contains information about the network connections on the device including interface type, link status, packets transmitted and received.

AT group: contains information about the ARP entries on the device including the values for MAC Address and IP Address for each entry.

IP group: contains IP statistics and configuration on the device including IP packets received, packets discarded, and IP address and subnet mask.

ICMP group: contains statistics for ICMP statistics including packets sent for redirect, port unreachable, or echo requests (Ping).

UDP group: contains statistics for UDP including packets received and transmitted, and packets sent to a UDP port with no listener.

SNMP group: contains statistics for the SNMP protocol including packets received and transmitted, error packets, and number of set requests.

For more detail, MIB-II is fully specified in RFC1213, available at <http://www.faqs.org/rfcs/rfc1213.html>.

The Prima•Stratum supports a generation of SNMPv1 Traps. Traps are messages sent from the device's LAN port when specific events occur.

The following traps may be generated:

- coldStart: this trap is generated if the Prima•Stratum re-initializes itself after a configuration change.
- warmStart: this trap is generated if the Prima•Stratum re-initializes itself after a reset which does not involve a configuration change.
- authenticationFailure: this trap is generated when a login to the user interface or an SNMPv1 SetRequest failed because an incorrect password was given.
- enterprisespecific: these are Engage proprietary traps.

For more detail on the industry standard traps, please see <http://www.faqs.org/rfcs/rfc1157.html>.

Chapter 4

Configuration Examples

The following examples are generic in that they will properly configure the most basic Prima•Stratum, with one to four ports. Use only the portion of the example that matches the number of ports that are being configured.

Example 1: T1 Configuration for ESF Framing and B8ZS Coding

```
config
interface

Host Name PrimaStratum
Host Location Site A
Telnet On
UserTimeout Off
snmp off
snmp traps off

Interface LAN1
Auto On
IP Address 192.168.1.50/24
Port On
BroadcastRcv On

Interface LAN2
Auto On
IP Address 192.168.2.50/24
Port Off
BroadcastRcv On

Interface S1
Type T1
T1 Mode          Term
T1 Equalization  Off
T1 Data          Normal
T1 Clocking      GPS
T1 LBO          CSU      0dB
T1 Framing       ESF
T1 Coding        B8ZS
T1 IdleCharacter 0x7F
T1 TxUnderrunAIS Off
T1 Channels      Full

Interface S2
Type T1
T1 Mode          Term
T1 Equalization  Off
T1 Data          Normal
T1 Clocking      GPS
T1 LBO          CSU      0dB
T1 Framing       ESF
T1 Coding        B8ZS
T1 IdleCharacter 0x7F
T1 TxUnderrunAIS Off
```



```

T1 Channels      Full

Interface S3
Type T1
T1 Mode          Term
T1 Equalization  Off
T1 Data          Normal
T1 Clocking      GPS
T1 LBO           CSU      0dB
T1 Framing       ESF
T1 Coding        B8ZS
T1 IdleCharacter 0x7F
T1 TxUnderrunAIS Off
T1 Channels      Full

```

```

Interface S4
Type T1
T1 Mode          Term
T1 Equalization  Off
T1 Data          Normal
T1 Clocking      GPS
T1 LBO           CSU      0dB
T1 Framing       ESF
T1 Coding        B8ZS
T1 IdleCharacter 0x7F
T1 TxUnderrunAIS Off
T1 Channels      Full

```

Example 2: T1 Configuration for D4 Framing and AMI Coding

```

config
interface

Host Name PrimaStratum
Host Location Site A
Telnet On
UserTimeout Off
snmp off
snmp traps off

Interface LAN1
Auto On
IP Address 192.168.1.50/24
Port On
BroadcastRcv On

Interface LAN2
Auto On
IP Address 192.168.2.50/24
Port Off
BroadcastRcv On

Interface S1
Type T1
T1 Mode          Term
T1 Equalization  Off
T1 Data          Normal

```

T1 Clocking	GPS	
T1 LBO	CSU	0dB
T1 Framing	D4	
T1 Coding	AMI	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Interface S2

Type T1		
T1 Mode	Term	
T1 Equalization	Off	
T1 Data	Normal	
T1 Clocking	GPS	
T1 LBO	CSU	0dB
T1 Framing	D4	
T1 Coding	AMI	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Interface S3

Type T1		
T1 Mode	Term	
T1 Equalization	Off	
T1 Data	Normal	
T1 Clocking	GPS	
T1 LBO	CSU	0dB
T1 Framing	D4	
T1 Coding	AMI	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Interface S4

Type T1		
T1 Mode	Term	
T1 Equalization	Off	
T1 Data	Normal	
T1 Clocking	GPS	
T1 LBO	CSU	0dB
T1 Framing	D4	
T1 Coding	AMI	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Example 3: E1 Configuration for CRC4 Framing and HDB3 Coding

```

config
interface

Host Name PrimaStratum
Host Location Site A
Telnet On
UserTimeout Off
snmp off

```

snmp traps off

Interface LAN1

Auto On
IP Address 192.168.1.50/24
Port On
BroadcastRcv On

Interface LAN2

Auto On
IP Address 192.168.2.50/24
Port Off
BroadcastRcv On

Interface S1

Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing CRC4
E1 Coding HDB3
E1 IdleCharacter 0x7F
E1 TxUnderrunAIS Off
E1 Channels Full

Interface S2

Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing CRC4
E1 Coding HDB3
E1 IdleCharacter 0x7F
E1 TxUnderrunAIS Off
E1 Channels Full

Interface S3

Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing CRC4
E1 Coding HDB3
E1 IdleCharacter 0x7F
E1 TxUnderrunAIS Off
E1 Channels Full

Interface S4

Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing CRC4
E1 Coding HDB3
E1 IdleCharacter 0x7F
E1 TxUnderrunAIS Off

E1 Channels Full

Example 4: E1 Configuration for FAS Framing and AMI Coding

```
config
interface

Host Name PrimaStratum
Host Location Site A
Telnet On
UserTimeout Off
snmp off
snmp traps off

Interface LAN1
Auto On
IP Address 192.168.1.50/24
Port On
BroadcastRcv On

Interface LAN2
Auto On
IP Address 192.168.2.50/24
Port Off
BroadcastRcv On

Interface S1
Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing FAS
E1 Coding AMI
E1 IdleCharacter 0x7F
E1 TxUnderrunAIS Off
E1 Channels Full

Interface S2
Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing FAS
E1 Coding AMI
E1 IdleCharacter 0x7F
E1 TxUnderrunAIS Off
E1 Channels Full

Interface S3
Type E1
E1 Mode Term
E1 Equalization Off
E1 Data Normal
E1 Clocking GPS
E1 Framing FAS
```

```

E1 Coding          AMI
E1 IdleCharacter   0x7F
E1 TxUnderrunAIS  Off
E1 Channels        Full

```

Interface S4

```

Type E1
E1 Mode           Term
E1 Equalization   Off
E1 Data           Normal
E1 Clocking       GPS
E1 Framing        FAS
E1 Coding         AMI
E1 IdleCharacter   0x7F
E1 TxUnderrunAIS  Off
E1 Channels        Full

```

Example 5: T1 and E1 Configuration

```

config
interface

```

```

Host Name PrimaStratum
Host Location Site A
Telnet On
UserTimeout Off
snmp off
snmp traps off

```

Interface LAN1

```

Auto On
IP Address 192.168.1.50/24
Port On
BroadcastRcv On

```

Interface LAN2

```

Auto On
IP Address 192.168.2.50/24
Port Off
BroadcastRcv On

```

Interface S1

```

Type T1
T1 Mode           Term
T1 Equalization   Off
T1 Data           Normal
T1 Clocking       GPS
T1 LBO            CSU      0dB
T1 Framing        ESF
T1 Coding         B8ZS
T1 IdleCharacter   0x7F
T1 TxUnderrunAIS  Off
T1 Channels        Full

```

Interface S2

```

Type T1
T1 Mode           Term

```

T1 Equalization	Off	
T1 Data	Normal	
T1 Clocking	GPS	
T1 LBO	CSU	0dB
T1 Framing	ESF	
T1 Coding	B8ZS	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Interface S3

Type E1	
E1 Mode	Term
E1 Equalization	Off
E1 Data	Normal
E1 Clocking	GPS
E1 Framing	CRC4
E1 Coding	HDB3
E1 IdleCharacter	0x7F
E1 TxUnderrunAIS	Off
E1 Channels	Full

Interface S4

Type E1	
E1 Mode	Term
E1 Equalization	Off
E1 Data	Normal
E1 Clocking	GPS
E1 Framing	CRC4
E1 Coding	HDB3
E1 IdleCharacter	0x7F
E1 TxUnderrunAIS	Off
E1 Channels	Full

Example 6: T1 and E1 Configuration for OCXO

```

config
interface

Host Name PrimaStratum
Host Location Site A
Telnet On
UserTimeout Off
snmp off
snmp traps off

Interface LAN1
Auto On
IP Address 192.168.1.50/24
Port On
BroadcastRcv On

Interface LAN2
Auto On
IP Address 192.168.2.50/24
Port Off
BroadcastRcv On

```

Interface S1

Type T1		
T1 Mode	Term	
T1 Equalization	Off	
T1 Data	Normal	
T1 Clocking	OCXO	
T1 LBO	CSU	0dB
T1 Framing	ESF	
T1 Coding	B8ZS	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Interface S2

Type T1		
T1 Mode	Term	
T1 Equalization	Off	
T1 Data	Normal	
T1 Clocking	OCXO	
T1 LBO	CSU	0dB
T1 Framing	ESF	
T1 Coding	B8ZS	
T1 IdleCharacter	0x7F	
T1 TxUnderrunAIS	Off	
T1 Channels	Full	

Interface S3

Type E1		
E1 Mode	Term	
E1 Equalization	Off	
E1 Data	Normal	
E1 Clocking	OCXO	
E1 Framing	CRC4	
E1 Coding	HDB3	
E1 IdleCharacter	0x7F	
E1 TxUnderrunAIS	Off	
E1 Channels	Full	

Interface S4

Type E1		
E1 Mode	Term	
E1 Equalization	Off	
E1 Data	Normal	
E1 Clocking	OCXO	
E1 Framing	CRC4	
E1 Coding	HDB3	
E1 IdleCharacter	0x7F	
E1 TxUnderrunAIS	Off	
E1 Channels	Full	

Chapter 5

Command Line Interface

The Prima•Stratum Command Line can be accessed with a serial connection to the Console port or a Telnet connection via the Ethernet interface.

For communication through the Console port, almost any standard terminal communication software can be used such as Hyperterm or Teraterm. The console port can be utilized to communicate with the Prima•Stratum locally, through a terminal, or remotely by dialing in through a modem.

Telnet, part of the TCP/IP Protocol Suite, provides a general communications facility defining a standard method of interfacing terminal devices to each other. Any standard Telnet application can be used to communicate to an Engage Prima•Stratum provided there is IP connectivity between the User Host and the Prima•Stratum.

Console Communication

Serial communication to the console port should be configured for,

9600 baud, 1 stop bit, no parity, 8 bit data, flow control none.

The console port is an RJ45 jack, and an appropriate cable and adapter are provided with the Prima•Stratum for use with standard 9 pin COM ports. The RJ45 console port is configured as a DCE, (data communication equipment), port.

Upon connecting enter a <cr> and a **LOGIN** prompt will appear.

The default **Login** ID is **root**.

No password is needed until the user sets it with the **PASSWD** command.

Logging in to the Prima•Stratum

A Telnet session is opened by providing the IP address of the Prima•Stratum. On opening a Command Line Interface, (CLI), session, via Telnet or the Console port, the **Login** prompt requires entry of a login ID.

The default login ID: **root**.

The Prima•Stratum is shipped with no password set. Passwords are set or modified with the **passwd** command, detailed below.

Overview of Commands

The Engage CLI supports shorthand character entry. At most, 3 characters are required for the parsing of the commands. For example, **show configuration** can be entered as: **sh con**. The CLI is not case sensitive. Description of the commands uses both upper and lower case for syntax definitions and examples.

A full description of the command line interface follows.

Categories

The command set can be divided into four categories:

- General
- Show
- Config
- Config Interface

Online Help

Included in the General commands is the HELP command, providing information on the entire command set. The Help command can be used in or out of the configuration modes.

Configuration Modes

For the Config and Config Interface commands, Engage employs a model approach. The user enters the Config mode with the **CONFIG** command, makes changes, then **SAVEs** those changes. **END** enables you to exit the config mode without making any changes.

The Config Interface mode, within the Config mode, is used to set parameters for a specified interface. Once in the Configuration mode, the user enters the **INTERFACE** command specifying the port that is to be configured. All subsequent commands apply to the specified interface.

Example:

```
name## INTERFACE S1
```

The command prompt indicates the mode of operation:

```
name#        the single “#” indicates standard Telnet mode
```

```
name##      indicates the Prima•Stratum is in the Config mode
```

```
name(LAN1)##      Prima•Stratum is in Config Interface mode for LAN Port 1
```

To move up one level, from Interface Config mode to Config mode, enter the **INTERFACE** command with no argument. To change between interfaces when in Interface Config mode, specify the new interface. For example:

```
name(s1)## INTERFACE LAN1
```

Syntax for Command Parameters

{ } == one of the parameters in set is required

[] == one of the parameters in set is allowed (optional)

Show Config All

The **SHOW CONFIG ALL** command provides the means to store and replay an entire configuration. Using a cut and paste operation, configurations may be edited off-line, stored and used later to configure the Prima•Stratum unit .

System Level or "General" Commands

CONFIG

Enter the configuration mode, with the command **CONFIG**, at which point the following commands may be used:

SAVE

Save the changes and exit Configuration mode.

END [SAVE]

Exit Configuration mode. The optional SAVE instructs the Prima•Stratum to save configuration changes.

RESTORE

Restores the current Prima•Stratum configuration, ignoring any changes which have been made during the current Telnet **CONFIG** session.

PASSWD

Allows setting or modifying the login password. The Prima•Stratum ships with no password set. Upon entering the **PASSWD** command, the user is prompted to enter, and confirm, the new password.

BYE | QUIT | LOGOUT

Any of these commands will terminate the Telnet session. If you have unsaved configuration changes, you will be prompted to save or discard the new configuration.

RESET

Resets the Prima•Stratum.

HELP [HELP | ALL | CONFIG | SHOW]

Provides Help information on a selected list of topics. Typing **HELP** with no argument provides the Help summary screen which is the top-level list of commands.

CLEAR {LAN1 | LAN2 | S1 | S2 | S3 | S4 | All}

Clears the port statistics on the selected port: Ethernet, LAN Port 1, etc.

HOST NAME namestring

Provide a unique name for the Prima•Stratum. The new host name does not take effect until a save and reset is performed.

Example:

HOST NAME Aptos PrimaStratum

Note: Earlier versions of the Engage software use the term **ROUTER NAME**.

TELNET {ON | OFF}

Turns the ability to telnet into a Prima•Stratum unit On and Off.

USER TIMEOUT {Off | 1-60}

This setting can be turned Off or set to the number of minutes you can leave your console or telnet session idle before the system automatically logs you out. If logged off, you must simply log on again.

Note: Setting this value to Off or zero disables automatic user logout.

TERM NN

Allows the user to tailor the number of display lines to their terminal screen size.

IP DEFAULT-ROUTER address

Configures the IP address of the default router or gateway for this Unit. This default router is the system's default router and is used when a specific interface is not set to a higher precedence default router with the Interface config command, **IP Default-router**.

PING {dest.address} [src.address] [[{number}]]spray]

Sends an ICMP ECHO message to the specified address. Any source address from an interface on the Prima•Stratum can be used. This can be useful to test routes across a LAN or WAN interface.

By default, only 1 message, (packet), is sent. A numeric value can be entered to send more than one message. Also, **SPRAY** can be used to continually send messages until the ESC key is pressed.

Upgrade Firmware

UPGRADE {TFTP Server Addr} {Filename}

TFTP, (trivial file transfer protocol), provides a means for upgrading Prima•Stratum firmware in a TCP/IP environment. A TFTP upgrade can be accomplished by acquiring the upgrade file from Engage Communication Technical Support and placing it on your own local TFTP server.

Example:

UPGRADE 157.22.234.129 58.72.64_upgrade.upg

Ensure IP connectivity between the Prima•Stratum and the TFTP server by pinging from one to the other. Then issue the upgrade command.

Note: A Prima•Stratum which is running an upgrade must go through a reset. This may cause a Telnet connection to drop. If this does occur, simply re-establish the Telnet connection.

SNMP Configuration

SNMP {ON | OFF}

Turns **ON** or **OFF** receipt and transmission of standard SNMP queries, excluding traps.

Note: **OFF** disables processing and responses to standard SNMP queries, excluding traps.

SNMP COMMUNITYNAME [ReadWrite]

Set or modify Prima•Stratum SNMP community name. This string is used for authentication of SNMP SetRequests and SNMP traps.

The default community name is "public".

Note: Do not enter a pass phrase to create the host key or password.

Example: SNMP Community Name Read (Get) Only

```
PrimaStratum#snmp communityname
Enter new password:<password string not echoed>
Confirm new password:<password string not echoed>
PrimaStratum#
```

Example: SNMP Community Name Read Write (Set/Get)

```
PrimaStratum#snmp communityname readwrite
Enter new password::<password string not echoed>
Confirm new password::<password string not echoed>
PrimaStratum#
```

SNMP TRAPS {ON | OFF}

Turns **ON** or **OFF** generation of SNMPv1 Traps. The Destination Address for these traps must be configured to be an SNMP management station capable of decoding SNMPv1 traps.

SNMP TRAPS ADDRESS address

Sets the Destination IP Address to which the Prima•Stratum will send SNMPv1 Traps.

SHOW Commands

SHOW INTERFACE [LAN1 | LAN2 | S1 | S2 | S3 | S4] {INFO | STATISTICS}

Provides details on any LAN or serial interface. If no interface is specified, either the current interface, per the “**Interface**” command will be used, or all interfaces will be shown.

INFO

Details the port type, port state, GPS lock state, antenna fault state, GPS holdover state, etc.

STATISTICS

Lists the packets received and transmitted, errors, etc.

SHOW ROUTER

Provides general configuration and status information, including the Ethernet hardware addresses and the firmware version.

SHOW IP STATISTICS

Provides more detailed statistics on IP packets only.

SHOW CONFIG ALL

Provides a list of all configuration parameters. No argument is the same as ALL. This list provides the basis for storing a Prima•Stratum configuration into a local text file. The full configuration can be edited in a text editor for simple "cut and paste" configuration of the unit.

SHOW CONFIG INTERFACE [LAN1 | LAN2 | S1 | S2 | S3 | S4]

If no interface is specified, either the current interface per the "interface" command will be used, or all interfaces will be shown.

SHOW CONFIG IP [ALL]

Details the IP configuration. No argument is the same as ALL, which provides configuration items which don't pertain to a specific port, i.e., default router, gateway, etc.

SHOW CONFIG ROUTER

Lists Prima•Stratum Hostname, IP Address, etc.

SHOW SSHD INFO

Use the Show Info or Show SSHD Info to determine the state of the SSHD Server.

LAN Interface Statistics**Packets Received**

The number of LAN packets received.

Receive CRC

The packet had a CRC error.

Receive Overrun

Overrun of internal FIFO used in transfer of LAN data to memory, or a frame was received and discarded due to lack of buffers, or a large frame was received.

Receive Framing

A non-octet aligned frame was received.

Receive Misc

A short frame was received, or a general error indicating an unexpected result in a buffer descriptor, or a buffer that was not a complete frame was received on the Ethernet channel.

Packets Transmitted

Number of LAN packets transmitted.

Transmit CSL

Carrier sense lost during frame transmission.

Transmit UN

Underrun, the Ethernet controller encountered a transmitter underrun while sending a buffer.

Transmit RL

Retransmission Limit. The transmitter failed attempts to successfully send a message due to repeated collisions (statistic not set on Prima•Stratum).

Transmit LC

Late collision. A collision occurred after 64 bytes are sent (statistic not set on Prima•Stratum).

Transmit Misc

Unspecified transmit error not associated with a buffer.

Serial Interface Information

Port Type

Shows if the port is set up as T1 or E1.

Connection State

Reports **Connected** when the port is receiving proper framing. This will turn on the LNK LED.
Reports **Not Connected** otherwise.

GPS Lock Status

Reports **Locked** if GPS module is locked to satellite signal.
Reports **Not Locked** when GPS has lost satellite signal.

Antenna Fault Status

Reports **No Fault** if the antenna is working properly.
Reports **Fault Detected** when a fault is detected with the antenna supply voltage.

GPS Holdover Status

Reports **Not In Holdover** if antenna is not in holdover.
Reports **In Holdover** when antenna is in holdover – keeping the last frequency present when it was last locked to the GPS signal.

Serial Interface Statistics

Not relevant for Prima•Stratum product.

SSHD Information

SSHD: Off

The SSHD server is configured off. No connections are accepted. If configured On, on unit start up the SSHD server will be in this state for a very short time until the SSHD server is started.

SSHD: No Host Key, Run SSHD HostKey Enter

A connection was attempted, but the SSHD server does not have a valid host key. Use the SSHD HostKey Enter command to configure a valid host key. Do not enter a pass phrase.

SSHD: Stopped

A brief transient state when SSHD is stopped during a configuration save operation.

SSHD: Running - No active session

The SSHD Server is running and ready to accept incoming connections, but no session is currently active.

SSHD: Running - Session active

An SSH session is currently active.

Config Interface Commands

Configuration of the Prima•Stratum involves setting parameters for the Ethernet interfaces, (LAN1 and LAN2), and the Serial interfaces, (**S1 | S2 | S3 | S4**), which may be T1 or E1 interfaces. The user must specify which interface is being configured with the command:

```
INTERFACE [LAN1 | LAN2 | S1 | S2 | S3 | S4]
```

Example:

```
name(s1)## INTERFACE LAN1
```

Local Area Network Interfaces

PORT {OFF | ON}

PORT enables or disables the Ethernet interface.

AUTONEGOTIATION {ON | OFF}

Enable or disable IEEE 802.3 Auto-Negotiation on the Ethernet interface.

Warning: If the device connected to LAN1 uses Auto-Negotiation and LAN1 is configured to use full duplex without Auto-Negotiation, the other device may operate in half duplex mode by default and successful operation cannot be guaranteed.

DUPLEX {HALF | FULL}

Sets the duplex mode for the Ethernet interface. This command only takes effect when Auto-negotiation is configured to **OFF**.

SPEED {10 | 100}

Sets the line rate in Mbps for the Ethernet interface. This command only takes effect when Auto-Negotiation is configured to **OFF**.

Note: Full Duplex and Speed of 10 has performance issues.

BROADCASTRCV {OFF | ON}

The Ethernet interface can be configured to disable the reception of Broadcast and Multicast packets. The IP protocol uses broadcast packets to resolve the Ethernet MAC Address of the destination IP.

BROADCASTRCV OFF requires that the destination Prima•Stratum or the Default Router and any local device that wants to communicate with the Prima•Stratum needs to be configured with the MAC address of the Prima•Stratum in its ARP table. Due to the complexity involved in setting up the IP Address to Ethernet MAC addresses manually it is recommended that **BroadcastRCV** is set to **ON** unless broadcast storms are expected on the network where the Prima•Stratums reside. For the Ethernet interface, first specify **INT**, (**Interface**), **LAN1**.

IP ADDRESS address[/mask]

The interface IP address and subnet mask are required for connection to the network, configuration with telnet or connectivity tests with ping. The subnet mask can be entered in long or short form.

Examples:

```
IP ADDRESS 192.168.1.1/255.255.255.0
```

```
IP ADDRESS 192.168.1.1/24
```

IP DEFAULT-ROUTER address

Configures the IP address of the default router or gateway for this Ethernet interface. This must be an IP address on the same network as the Prima•Stratum Ethernet interface. This default router takes precedence over the system's default router. Note: If DHCP is ON for this LAN interface the Default-Router/Gateway is discovered.

DHCP Client**DHCPCLIENT {ON | OFF}**

Enables or disables IP address requesting for this LAN port via DHCP. When a DHCP server has granted us an IP address it is displayed in the configuration.

ON enables this LAN port to send DHCP discovery packets and use the IP address that a DHCP server will assign to it.

OFF disables DHCP discovery and relies on the user's setting of LAN's IP address

Note: DHCP discovery will take precedence the LAN specific IP address and default router settings, but not the OurDNSServer setting.

SSHD {On | Off}

Enables or disables the SSH Server.

SSHD Port <port number>

Specifies the TCP port number for incoming SSH sessions.

SSHD HostKey Enter <OpenSSH DSA Key>

Configures the SSH Server host key. The SSH Server must have a host key for an SSH Client to accept a connection from the Server. The <OpenSSH DSA Key> must be in OpenSSH format.

Units shipped with this base firmware or later versions have an SSH Server host key already configured. Use this command to change the host key.

Units running base firmware that did not previously support SSH will need to run this command after an upgrade to a version that supports SSH.

Most SSH Client software have the facility to generate an OpenSSH host key. The text of a key generated by client software can be used as the <OpenSSH DSA Key> in the SSHD HostKey Enter command.

Note: When creating a key do not enter a pass phrase.

Note: There will be two keys generated when creating a key, use the file without the '.pub' extension.

Example:

OpenSSH provides the sys-keygen program. Run:
ssh-keygen -b 1024 -t dsa -f <filename>

ssh-keygen creates a private key in filename and a public key in filename.pub. Enter the text of the private key as the <OpenSSH DSA Key> in the SSHD HostKey Enter command.

SecureCRT can create an OpenSSH format private key. In the tools menu, select Create Public Key. Execute the Key Generation wizard to create a client key (the client key can be used as a host key). Choose type DSA and 1024 bits. Select OpenSSH format when it saves the private key in a file. Used the saved file as the input to the SSHD HostKey Enter command.

Changing a host key can have repercussions amongst clients. The next time they connect to the server, they may prompt the user if they want to continue even though the Server key has changed or refuse the connection entirely.

Troubleshooting SSHD

If an SSH client cannot make a connection to the Prima•Stratum, check the following items.

Make sure the SSHD is configured on.

Check the SSHD Port number is the same as the Client attempting the connection.

Look at the "Show SSHD Info" status. Check if SSHD is On, or there is already a session active (only one allowed), or the host key is not valid.

Use the Client logging facilities to gather information about the failed connection attempt. For the OpenSSH client, use the -vvv option.

For the SecureCRT client, select the Raw Log Options from the File menu.

T1 Interface

The following Serial Interface commands are applicable to Prima•Stratum model T1 interface configurations.

TYPE {T1 | E1}

The **TYPE** parameter is user configurable to match the Serial port's hardware and should be set to **T1**.

T1 DATA {NORMAL | INVERTED}

Can be set for **Normal** or **Inverted** and must match the setting of the DSU/CSU on the other end.

T1 TXUNDERRUN AIS {ON | OFF}

ON Enable the transmission of an unframed All Ones BLUE Alarm Code out the T1 interface if the T1 transmitter underruns.

OFF disables generation of an **AIS**.

Note: Not relevant for Prima•Stratum product.

T1 CLOCKING {GPS | OCXO | GPSBackupOCXO}

Determines the source of Transmit Clock (TxCk). When set to **GPS**, the DSU/CSU transmits clocking at a Stratum 1 rate set by a GPS Antenna.

When set to **OCXO**, the DSU/CSU transmits clocking at a Stratum IIIe rate set by an internal oven controlled oscillator.

Note: T1 Clocking **OCXO** is only available for the Prima•Stratum as an upgradable option.

T1 Equalization {ON | OFF}

T1 Equalization must be **OFF**.

T1 MODE {Term | Monitor}

Sets the interface mode of T1 interface. **Term** is used when the T1 interface is the only one connecting to the T1 device. This setting should always be set for **Term**.

T1 LBO {CSU {0dB | -7.5dB | -15 dB | -22.5dB} | DSX-1 NNN}

This setting determines the transmitted data (TxD) waveform to compensate for attenuation on the T1 line. Typically, **Line Build Out** is set to the **CSU** mode, where the build out is specified in dB. In applications where the T1 cabling is short, (the T1 interface is within 20 feet of the network termination), set **T1 LBO** for **0 dB**.

T1 FRAMING {ESF | D4}

Selects whether **ESF**, (Extended Super Frame), or **D4** framing is to be used. This parameter is determined by the T1 equipment interface.

T1 CODING {B8ZS | AMI}

Selects whether **B8ZS** or **AMI**, (Alternate Mark Inversion), line coding is used. The T1 service provider will specify.

T1 IDLECHARACTER 0xNN

Not needed for Prima•Stratum operation.

T1 CHANNELS {FULL}

FULL will utilize all channels.

E1 Interface

The Prima•Stratum is available with an E1 interface, providing connection speeds up to 2.048 Mbps. The following Serial Interface commands are applicable to Prima•Stratum models connecting to E1 interfaces. The serial interface commands include those for the E1 DSU/CSU parameters.

TYPE {T1 | E1}

The **TYPE** parameter is user configurable to match the Serial port's hardware and should be set to **E1**.

E1 TXUNDERRUN AIS {ON | OFF}

ON Enable the transmission of an unframed All Ones BLUE Alarm Code out the E1 interface if the E1 transmitter underruns.

OFF disables generation of an **AIS**.

Note: Not relevant for Prima•Stratum product.

E1 DATA {NORMAL | INVERTED}

Can be set for **Normal** or **Inverted** and must agree with the setting of the DSU/CSU on the other end.

E1 CLOCKING {GPS | OXCO | GPSBackupOXCO}

Determines the source of Transmit Clock (TxCk). When set to **GPS**, the DSU/CSU transmits clocking at a Stratum 1 rate set by a GPS Antenna.

When set to **OXCO**, the DSU/CSU transmits clocking at a Stratum IIIe rate set by an internal oven controlled oscillator.

Note: T1 Clocking **OXCO** is only available for the Prima•Stratum as an upgradable option.

E1 Equalization {ON | OFF}

E1 Equalization must be **OFF**.

E1 MODE {Term | Monitor}

Sets the interface mode of E1 interface. Term is used when the E1 interface is the only one connecting to the E1 device. This setting should always be set for **Term**

E1 FRAMING {CRC4 | FAS | UNFRAMED}

Selects the desired E1 framing format, including **Unframed**.

E1 CODING {HDB3 | AMI}

Selects whether **HDB3** or **AMI**, (Alternate Mark Inversion), line coding is used.

E1 IDLE CHARACTER 0xNN

Not needed for Prima•Stratum operation.

E1 CHANNELS {FULL}

FULL will utilize all channels.

Chapter 6

Prima•Stratum Configuration & Operation

This chapter provides operational theory and configuration details specific to the Prima•Stratum for T1's and E1's. With built-in DSU/CSU interfaces, these models have unique requirements regarding their interface to other T1/E1 equipment.

Prima•Stratum Installation Steps

The process of installing a Prima•Stratum involves the following steps:

- Installing the Prima•Stratum hardware
- Configuring System and Ethernet parameters
- Configuring the Prima•Stratum interface parameters
- Making Ethernet, T1/E1 and GPS cabling connections
- Verifying Prima•Stratum connectivity

Note: A T1/E1 crossover cable is typically required to connect the Prima•Stratum T1/E1 interface to the external T1/E1 equipment, which is supplied with shipment.

System and Ethernet Parameters

The Prima•Stratum System parameters and LAN interface configuration items are described in Chapter 5: *Command Line Interface* for specific syntax requirements. This portion of the manual is dedicated to the installation parameters associated with the T1 and E1 interfaces.

T1 Parameters

T1 interface commands are configured by first selecting **INTERFACE S1**, (these ports are marked on the Prima•Stratum as "Tel1", "Tel2", "Tel3", "Tel4").

T1 DSU/CSU Parameters

The Prima•Stratum T1 serial interface number 1, S1, is configured for T1 operation. The following T1 parameters must match the configuration of the DS1/T1 interface to which it is connected. **Note: T1 Clocking is global for all ports, controlled by S1.**

Interface S1

Type	T1
T1 Mode	{Term Monitor}
T1 Data	{Normal Invert}
T1 Clocking	{GPS OCXO GPSBackupOCXO}
T1 LBO	{CSU {0dB -7.5dB -15 dB -22.5dB} DSX-1 NNN}}
T1 Framing	{ESF D4}
T1 Coding	{B8ZS AMI}
T1 IdleCharacter	0xNN
T1 Channels	{Full}

Note: T1 Clocking OCXO is available as an upgradable option.

E1 Parameters

The Prima•Stratum E1 parameters are similar to those for T1 except as noted here:

E1 DSU/CSU Parameters

The following E1 parameters must match the configuration of the E1 interface to which it is connected. The E1 clock setting is dependent upon the source of the E1 Clock. **Note: E1 Clocking is global for all ports, controlled by S1.**

Interface S1

Type E1	
E1 Mode	{Term Monitor}
E1 Data	{Normal Invert}
E1 Clocking	{GPS OCXO GPSBackupOCXO}
E1 Framing	{CRC4 FAS Unframed}
E1 Coding	{HDB3 AMI}
E1 IdleCharacter	0xNN
E1 Channels	{Full}

Note: E1 Clocking OCXO is available as an upgradable option.

T1/E1 Clocking Considerations

When set to **GPS**, the DSU/CSU transmits clocking at a Stratum 1 rate set by a GPS Antenna.

When set to **OCXO**, the DSU/CSU transmits clocking at a Stratum IIIe rate set by an internal oven controlled oscillator.

Note: T1 Clocking **OCXO** is only available for the Prima•Stratum as an upgradable option.

Prima•Stratum Cabling

The Prima•Stratum use standard or crossover 10/100BaseT Ethernet cabling to connect to any Ethernet equipment. The cabling that is used to connect the Prima•Stratum T1 Port or E1 Port to the T1/E1 interface depends upon the equipment it is connecting to. In the case of a connection to the interface of T1/E1 Equipment a crossover cable is required. Refer to the *Appendices* for the details of the wiring of this cable. Connections to T1 lines is done with a standard T1 cable. An E1 connection utilizes the RJ45 to DB15 male adapter and standard RJ45 cabling with all 8 connections.

Appendix

Prima•Stratum Specifications

GPS Locked Frequency Stability

- GPS Locked - Stratum 1 timing

GPS Holdover Frequency Stability - TCXO (loss of satellite signal)

- Temperature Stability ± 0.5 ppm
- Vcc Stability 0.1 ppm
- Yearly Aging 2 ppm

OCXO Frequency Stability - Stratum IIIe

- Stability Vs. Voltage ($\pm 5\%$ Change) ± 2 PPB
- Short Term Aging (3 weeks min operation) ± 0.5 PPB/Day
- Long Term Aging (After 60 days operation) ± 50 PPB/Year

GPS Antenna Cable Specifications

- 50 Ω BNC maximum RG-58 cable length - 10 meters (30 feet) - Included with antenna option
- 50 Ω BNC maximum LMR-400 cable length - 150 feet
- 50 Ω BNC maximum LMR-500 cable length - 200 feet
- 50 Ω BNC maximum LMR-600 cable length - 250 feet
- Antenna cable is active - DC voltage is needed for antenna operation - Using line amplifiers is **not** recommended, it will damage the device.

Ethernet Port

- 10/100 BaseT Full/Half Ethernet

Serial Interfaces Options

- T1 DSU/CSU
- E1 DSU/CSU

Power Supply

- External 12 Volts DC, 3Amp, with standard AC plug. International power supplies available

Physical

- Standard 19 inch rack mount kit available
- Dimensions: 6.0 x 4.0 x 1.5 inches
- Weight: approximately 1 lbs., excluding external power adapter

T1 Specifications

- One to Four Port Models
- Connects directly to T1 Line or to a DS1 interface with a Crossover Cable
- Framing - ESF or D4
- Coding - B8ZS or AMI
- Supports DS0 assignments from 1 to 24
- Non-Contiguous Configuration x-y,z supported

E1 Specifications

- One to Four Port Models
- Connects directly to E1 Line or to a DS1 interface with a Crossover Cable
- Framing - E1Framed or Transparent
- Coding - HDB3 or AMI
- Supports DS0 assignments from 1 to 24
- Not Contiguous Configuration x-y,z Supported

TFTP Online Upgrade Capable (FLASH ROMs)

- Prima•Stratum can be upgraded remotely using TFTP

Management

- Telnet support with Edit and Paste Template Files (See Chapter 4: *Configuration Examples*)
- Console Port for Out of Band Management
- SNMP support (MIB I, MIB II)
- Remote configuration & monitoring


Prima•Stratum Dip Switch Settings-All Models

The Prima•Stratum has a single push-button switch (SW2). When holding this switch during the boot cycle it will do the following:

- Force operation from Base Flash and delete downloaded upgrades.

The rear panel must be removed and the motherboard slid out slightly to access the switch.

10/100BaseT Port Specification with Crossover cable pinout



10BaseT Plug pin numbering


Pin 1	TxD+
Pin 2	TxD-
Pin 3	RxD+
Pin 6	RxD-

For 10BaseT Crossover (allowing connection directly between two 10BaseT devices) wire:

(TD+)	Pin 1	to	Pin 3	(RD+)
(TD-)	Pin 2	to	Pin 6	(RD-)
(RD+)	Pin 3	to	Pin 1	(TD+)
(RD-)	Pin 6	to	Pin 2	(TD-)

Table 1 - 10/100BaseT Port Specification

T1 and E1 Port Specification with Crossover Pinouts



T1/fracT1 DSU/CSU Pin numbering

1	RxRing
2	RxTip
4	TxRing
5	TxTip

For T1 Crossover (allowing connection directly between two T1/fracT1 DSU/CSU devices) wire:

(TxTip)	Pin 5	to	Pin 2	(RxTip)
(TxRing)	Pin 4	to	Pin 1	(RxRing)
(RxRing)	Pin 1	to	Pin 4	(TxRing)
(RxTip)	Pin 2	to	Pin 5	(TxTip)

Table 2 - 10/100BaseT Port Specification #2

E1 RJ45 to db15 Cable

Signal	RJ45	db15 Male
TxD Tip	5	1
RxD Tip	2	3
TxD Ring	4	9
RxD Ring	1	11

Table 3 - RJ45 to DB9 Cable Pinout

Console Port Information

RJ45 Console Port Pinout


RJ45 pin	Signal Name
3	TxData
6	RxData
1	RTS
8	CTS
4	Gnd
2	DTR

RJ45/db9F Null Modem Adapter

RJ45 pin	db9pin
3	2
6	3
1	8
4	5
2	6

Table 4 - Console Port Pinout


12 - 24 VDC Screw Terminal Interface Specifications



GND:	Ground
FGND:	Frame Ground
+VDC:	12 - 24 DC Voltage

Table 5 - 12 - 24 DCV Power Connector

-48V Interface Specifications



-48V:	-48 Voltage
FRM GND:	Frame Ground
RET:	Return

Table 6 - -48 Power Connector

Copyright Notices:

The Engage Communications, Inc. SSH incorporates components of OpenSSH and OpenSSL software. Here are the necessary copyright notices.

OpenSSH Copyright notices:

This file is part of the OpenSSH software.

The licenses which components of this software fall under are as follows. First, we will summarize and say that all components are under a BSD license, or a license more free than that.

OpenSSH contains no GPL code.

1)

* Copyright (c) 1995 Tatu Ylonen <ylo@cs.hut.fi>, Espoo, Finland
* All rights reserved
*

* As far as I am concerned, the code I have written for this software
* can be used freely for any purpose. Any derived versions of this
* software must be clearly marked as such, and if the derived work is
* incompatible with the protocol description in the RFC file, it must
be
* called by a name other than "ssh" or "Secure Shell".

[Tatu continues]

* However, I am not implying to give any licenses to any patents or
* copyrights held by third parties, and the software includes parts
that
* are not under my direct control. As far as I know, all included
* source code is used in accordance with the relevant license
agreements
* and can be used freely for any purpose (the GNU license being the
most
* restrictive); see below for details.

[However, none of that term is relevant at this point in time. All of these restrictively licensed software components which he talks about have been removed from OpenSSH, i.e.,

- RSA is no longer included, found in the OpenSSL library
- IDEA is no longer included, its use is deprecated
- DES is now external, in the OpenSSL library
- GMP is no longer used, and instead we call BN code from OpenSSL
- Zlib is now external, in a library
- The make-ssh-known-hosts script is no longer included
- TSS has been removed
- MD5 is now external, in the OpenSSL library
- RC4 support has been replaced with ARC4 support from OpenSSL
- Blowfish is now external, in the OpenSSL library

[The license continues]

Note that any information and cryptographic algorithms used in this software are publicly available on the Internet and at any major bookstore, scientific library, or patent office worldwide. More

information can be found e.g. at "<http://www.cs.hut.fi/crypto>".

The legal status of this program is some combination of all these permissions and restrictions. Use only at your own responsibility. You will be responsible for any legal consequences yourself; I am not making any claims whether possessing or using this is legal or not in your country, and I am not taking any responsibility on your behalf.

NO WARRANTY

BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

2)

The 32-bit CRC compensation attack detector in deattack.c was contributed by CORE SDI S.A. under a BSD-style license.

```
* Cryptographic attack detector for ssh - source code
*
* Copyright (c) 1998 CORE SDI S.A., Buenos Aires, Argentina.
*
* All rights reserved. Redistribution and use in source and binary
* forms, with or without modification, are permitted provided that
* this copyright notice is retained.
*
* THIS SOFTWARE IS PROVIDED ``AS IS'' AND ANY EXPRESS OR IMPLIED
* WARRANTIES ARE DISCLAIMED. IN NO EVENT SHALL CORE SDI S.A. BE
* LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY OR
* CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OR MISUSE OF THIS
* SOFTWARE.
*
* Ariel Futoransky <futo@core-sdi.com>
* <http://www.core-sdi.com>
```

3)

ssh-keyscan was contributed by David Mazieres under a BSD-style license.

* Copyright 1995, 1996 by David Mazieres <dm@lcs.mit.edu>.

*

* Modification and redistribution in source and binary forms is

* permitted provided that due credit is given to the author and the

* OpenBSD project by leaving this copyright notice intact.

4)

The Rijndael implementation by Vincent Rijmen, Antoon Bosselaers and Paulo Barreto is in the public domain and distributed with the following license:

* @version 3.0 (December 2000)

*

* Optimized ANSI C code for the Rijndael cipher (now AES)

*

* @author Vincent Rijmen <vincent.rijmen@esat.kuleuven.ac.be>

* @author Antoon Bosselaers <antoon.bosselaers@esat.kuleuven.ac.be>

* @author Paulo Barreto <paulo.barreto@terra.com.br>

*

* This code is hereby placed in the public domain.

*

* THIS SOFTWARE IS PROVIDED BY THE AUTHORS "AS IS" AND ANY EXPRESS
 * OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
 * WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
 * ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHORS OR CONTRIBUTORS BE
 * LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
 * CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF
 * SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR
 * BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY,
 * WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE
 * OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE,
 * EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

5)

One component of the ssh source code is under a 3-clause BSD license, held by the University of California, since we pulled these parts from original Berkeley code.

* Copyright (c) 1983, 1990, 1992, 1993, 1995

* The Regents of the University of California. All rights reserved.

*

* Redistribution and use in source and binary forms, with or without

* modification, are permitted provided that the following conditions

* are met:

* 1. Redistributions of source code must retain the above copyright

* notice, this list of conditions and the following disclaimer.

* 2. Redistributions in binary form must reproduce the above copyright

* notice, this list of conditions and the following disclaimer in

the

* documentation and/or other materials provided with the distribution.

- * 3. Neither the name of the University nor the names of its contributors
 - * may be used to endorse or promote products derived from this software
 - * without specific prior written permission.
 - *
 - * THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS IS'' AND
 - * ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
 - * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE
 - * ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE
 - * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL
 - * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS
 - * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
 - * HOWEVER, CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT
 - * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY
 - * OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF
 - * SUCH DAMAGE.

- 6) Remaining components of the software are provided under a standard 2-term BSD license with the following names as copyright holders:

Markus Friedl
 Theo de Raadt
 Niels Provos
 Dug Song
 Aaron Campbell
 Damien Miller
 Kevin Steves
 Daniel Kouril
 Wesley Griffin
 Per Allansson
 Nils Nordman
 Simon Wilkinson

Portable OpenSSH additionally includes code from the following copyright holders, also under the 2-term BSD license:

Ben Lindstrom
 Tim Rice
 Andre Lucas
 Chris Adams
 Corinna Vinschen
 Cray Inc.
 Denis Parker
 Gert Doering
 Jakob Schlyter
 Jason Downs
 Juha Yrjölä

Michael Stone
 Networks Associates Technology, Inc.
 Solar Designer
 Todd C. Miller
 Wayne Schroeder
 William Jones
 Darren Tucker
 Sun Microsystems
 The SCO Group

- * Redistribution and use in source and binary forms, with or without
 - * modification, are permitted provided that the following conditions
 - * are met:
 - * 1. Redistributions of source code must retain the above copyright
 - * notice, this list of conditions and the following disclaimer.
 - * 2. Redistributions in binary form must reproduce the above copyright
 - * notice, this list of conditions and the following disclaimer in
- the
- * documentation and/or other materials provided with the
- distribution.
- * THIS SOFTWARE IS PROVIDED BY THE AUTHOR ``AS IS'' AND ANY EXPRESS OR
 - * IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED
- WARRANTIES
- * OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE
- DISCLAIMED.
- * IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT,
 - * INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING,
- BUT
- * NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF
- USE,
- * DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY
 - * THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT
 - * (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE
- OF
- * THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

8) Portable OpenSSH contains the following additional licenses:

a) md5crypt.c, md5crypt.h

- * "THE BEER-WARE LICENSE" (Revision 42):
- * <phk@login.dknet.dk> wrote this file. As long as you retain this
- * notice you can do whatever you want with this stuff. If we meet
- * someday, and you think this stuff is worth it, you can buy me a
- * beer in return. Poul-Henning Kamp

b) snprintf replacement

- * Copyright Patrick Powell 1995
 - * This code is based on code written by Patrick Powell
 - * (papowell@astart.com) It may be used for any purpose as long as
- this
- * notice remains intact on all source code distributions

c) Compatibility code (openbsd-compat)

Apart from the previously mentioned licenses, various pieces of code in the opensbsd-compat/ subdirectory are licensed as follows:

Some code is licensed under a 3-term BSD license, to the following copyright holders:

Todd C. Miller
 Theo de Raadt
 Damien Miller
 Eric P. Allman
 The Regents of the University of California
 Constantin S. Svintsoff

* Redistribution and use in source and binary forms, with or without
 * modification, are permitted provided that the following conditions
 * are met:
 * 1. Redistributions of source code must retain the above copyright
 * notice, this list of conditions and the following disclaimer.
 * 2. Redistributions in binary form must reproduce the above
 copyright
 * notice, this list of conditions and the following disclaimer in
 the
 * documentation and/or other materials provided with the
 distribution.
 * 3. Neither the name of the University nor the names of its
 contributors
 * may be used to endorse or promote products derived from this
 software
 * without specific prior written permission.
 *
 * THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS ``AS
 IS'' AND
 * ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO,
 THE
 * IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR
 PURPOSE
 * ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE
 LIABLE
 * FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR
 CONSEQUENTIAL
 * DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE
 GOODS
 * OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS
 INTERRUPTION)
 * HOWEVER, CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER
 IN CONTRACT, STRICT
 * LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN
 ANY WAY
 * OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE
 POSSIBILITY OF
 * SUCH DAMAGE.

Some code is licensed under an ISC-style license, to the following copyright holders:

Internet Software Consortium.
 Todd C. Miller

Reyk Floeter
Chad Mynhier

* Permission to use, copy, modify, and distribute this software for any purpose with or without fee is hereby granted, provided that the above copyright notice and this permission notice appear in all copies.

* THE SOFTWARE IS PROVIDED "AS IS" AND TODD C. MILLER DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL TODD C. MILLER BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Some code is licensed under a MIT-style license to the following copyright holders:

Free Software Foundation, Inc.

* Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, distribute with modifications, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

* The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

* THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE ABOVE COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM,

* DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT
 OR *
 * OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE
 OR *
 * THE USE OR OTHER DEALINGS IN THE SOFTWARE.

*
 *
 *
 * Except as contained in this notice, the name(s) of the above
 copyright *
 * holders shall not be used in advertising or otherwise to promote
 the *
 * sale, use or other dealings in this Software without prior written
 *
 * authorization.
 *

/

\$OpenBSD: LICENSE,v 1.19 2004/08/30 09:18:08 markus Exp \$

OpenSSL Copyright notices:

LICENSE ISSUES

=====

The OpenSSL toolkit stays under a dual license, i.e., both the
 conditions of
 the OpenSSL License and the original SSLeay license apply to the toolkit.
 See below for the actual license texts. Actually, both licenses are
 BSD-style
 Open Source licenses. In case of any license issues related to OpenSSL
 please contact openssl-core@openssl.org.

OpenSSL License

```
/* =====
 * Copyright (c) 1998-2007 The OpenSSL Project. All rights reserved.
 *
 * Redistribution and use in source and binary forms, with or without
 * modification, are permitted provided that the following conditions
 * are met:
 *
 * 1. Redistributions of source code must retain the above copyright
 * notice, this list of conditions and the following disclaimer.
 *
 * 2. Redistributions in binary form must reproduce the above copyright
 * notice, this list of conditions and the following disclaimer in
 * the documentation and/or other materials provided with the
 * distribution.
 *
```

```

* 3. All advertising materials mentioning features or use of this
* software must display the following acknowledgment:
* "This product includes software developed by the OpenSSL Project
* for use in the OpenSSL Toolkit. (http://www.openssl.org/)"
*
* 4. The names "OpenSSL Toolkit" and "OpenSSL Project" must not be used to
* endorse or promote products derived from this software without
* prior written permission. For written permission, please contact
* openssl-core@openssl.org.
*
* 5. Products derived from this software may not be called "OpenSSL"
* nor may "OpenSSL" appear in their names without prior written
* permission of the OpenSSL Project.
*
* 6. Redistributions of any form whatsoever must retain the following
* acknowledgment:
* "This product includes software developed by the OpenSSL Project
* for use in the OpenSSL Toolkit (http://www.openssl.org/)"
*
* THIS SOFTWARE IS PROVIDED BY THE OpenSSL PROJECT ``AS IS'' AND ANY
* EXPRESSED OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE
* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR
* PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE OpenSSL PROJECT OR
* ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL,
* SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT
* NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES;
* LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)
* HOWEVER, CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT,
* STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE)
* ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED
* OF THE POSSIBILITY OF SUCH DAMAGE.
* =====
*
* This product includes cryptographic software written by Eric Young
* (eay@cryptsoft.com). This product includes software written by Tim
* Hudson (tjh@cryptsoft.com).
*
*/

```

Original SSLeay License

```

/* Copyright (C) 1995-1998 Eric Young (eay@cryptsoft.com)
* All rights reserved.
*
* This package is an SSL implementation written
* by Eric Young (eay@cryptsoft.com).
* The implementation was written so as to conform with Netscapes SSL.
*
* This library is free for commercial and non-commercial use as long as
* the following conditions are adhered to. The following conditions
* apply to all code found in this distribution, be it the RC4, RSA,
* lhash, DES, etc., code; not just the SSL code. The SSL documentation
* included with this distribution is covered by the same copyright terms
* except that the holder is Tim Hudson (tjh@cryptsoft.com).
*
* Copyright remains Eric Young's, and as such any Copyright notices in

```

* the code are not to be removed.

* If this package is used in a product, Eric Young should be given attribution

* as the author of the parts of the library used.

* This can be in the form of a textual message at program startup or

* in documentation (online or textual) provided with the package.

*

* Redistribution and use in source and binary forms, with or without

* modification, are permitted provided that the following conditions

* are met:

* 1. Redistributions of source code must retain the copyright

* notice, this list of conditions and the following disclaimer.

* 2. Redistributions in binary form must reproduce the above copyright

* notice, this list of conditions and the following disclaimer in the

* documentation and/or other materials provided with the distribution.

* 3. All advertising materials mentioning features or use of this software

* must display the following acknowledgement:

* "This product includes cryptographic software written by

* Eric Young (eay@cryptsoft.com)"

* The word 'cryptographic' can be left out if the routines from

the library

* being used are not cryptographic related .

* 4. If you include any Windows specific code (or a derivative thereof)

from

* the apps directory (application code) you must include an

acknowledgement:

* "This product includes software written by Tim Hudson

(tjh@cryptsoft.com)"

*

* THIS SOFTWARE IS PROVIDED BY ERIC YOUNG "AS IS" AND

* ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE

* IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR

PURPOSE

* ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE

* FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR

CONSEQUENTIAL

* DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS

* OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION)

* HOWEVER, CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN

CONTRACT, STRICT

* LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY

* OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF

* SUCH DAMAGE.

*

* The license and distribution terms for any publicly available version

or

* derivative of this code cannot be changed. i.e., this code cannot

simply be

* copied and put under another distribution license

* [including the GNU Public License.]

*/

Glossary

Terms and Concepts

Before using the Engage Prima•Stratum, you should be familiar with the terms and concepts that describe TCP/IP, Networking and T1/E1 Telecommunications.

General Networking Terms

Network

A network is a collection of computers, server devices, and communication devices connected together and capable of communication with one another through a transmission medium.

Internet

An internet is any grouping of two or more networks connected by one or more internet routers.

Network Services

Network services are the capabilities that the network system delivers to users, such as print servers, file servers, and electronic mail.

Addresses

Transmitting information in a network system is made possible by an addressing scheme that identifies the sender and destination of the transmission, using network and node addresses. Data is transmitted to and from these addresses in the form of packets.

Routing Table

A routing table is maintained in each router. This table lists all networks and routers in the internet and enables routers to determine the most efficient route for each packet. The routing table serves as a logical map of the internet, specifying the address of the next router in the path to a given destination network and the distance in hops. The router uses the routing table to determine where and whether to forward a packet.

Each router periodically broadcasts its routing table to other routers on each of its directly connected networks, enabling them to compare and update their own tables with the most recent record of connected networks and routes. In this way, routing tables are kept current as changes are made on the internet.

Hop

A hop is a unit count between networks on the internet. A hop signifies "one router away."

Node

Device on the network

TCP/IP Networking Terms

FTP

File Transfer Protocol gives users the ability to transfer files between IP hosts. It uses TCP to provide connection initiation and reliable data transfer.

Host

A computer with one or more uses that can act as an endpoint of communication if it has TCP/IP.

ICMP

Internet Control Message Protocol provides a means for intermediate gateways and hosts to communicate. There are several types of ICMP messages, and they are used for several purposes including IP flow control, routing table correction and host availability.

IP

Internet Protocol which routes the data.

IP Datagram

The basic unit of the information passed across and IP Internet. It contains address information and data.

PING

Packet InterNet Groper is a program which uses **ICMP** echo request message to check if the specifies IP address is accessible from the current host.

Port

A Destination point used by transport level protocols to distinguish among multiple destinations within a given host computer.

SubNet Address

An extension of the **IP** addressing scheme which enables an **IP** site to use a single **IP** address for multiple physical networks. Subnetting is applicable when a network grows beyond the number of hosts allowed for the **IP** address class of the site.

TCP

Transmission Control Protocol ensures reliable, sequential, delivery of data. **TCP** at each end of the connection ensures that the data is delivered to the application accurately, sequential, completely and free of duplicates. The application passes a stream of bytes to **TCP** which breaks it into pieces, adds a header, forming a segment, and then passes each segment to **IP** for transmission.

Telnet

The **TCP/IP** standard protocol for remote terminal connection service. A user can **telnet** from the local host to a host at a remote site.

UDP

User Datagram Protocol provides simple, efficient protocol which is connectionless and thus unreliable. The **IP** address contained in the **UDP** header is used to direct the datagram to a specific destination host.

Well-Known Port

Any set of port numbers reserved for specific uses by transport level protocols (**TCP** & **UDP**). Well-known ports exist for echo servers, time servers, **telnet** and **FTP** servers.

Other Terms

TCXO

Temperature Controlled Oscillator

OCXO

Oven Controlled Oscillator